


# SAFETYARC Modular Welding Curtains Assembly Instructions

## Complete welding frame with curtain



### Packed Box Size For Frame + Curtain


Packed Box Size :  
34" (860mm) x 12" (305mm) x 4½" (115mm)  
Qty in 20 ft FCL = 847 Pcs.



### Gross Weight :

SP-FC46PF : 8.5 Kg  
SP-FC66PF : 10.0 Kg  
SP-FC86PF : 11.6 Kg

## Welding Curtain Frame Only



### Packed Box Size For Metal Frame Only

Packed Box Size :  
34" (860mm) x 12" (305mm) x 3" (75mm)  
Qty in 20 ft FCL = 1200 Pcs.



### Gross Weight :

SP-F46 : 7.4 Kg  
SP-F66 : 8.4 Kg  
SP-F86 : 9.4 Kg

### Extendable Curtain Full Height :

Extendable curtains are supplied with side buttons for attaching / extending curtains.

Sizes	Curtain Only	Frame Only	Frame & Curtain
Full Length	Pkng: 10 pcs/box	Pkng: 1pc/box	Pkng: 1 set/box
4' x 6' (120x180cm)	SP-C46PF	SP-F46	SP-FC46PF
6' x 6' (180x180cm)	SP-C66PF	SP-F66	SP-FC66PF
8' x 6' (240x180cm)	SP-C86PF	SP-F86	SP-FC86PF
10' x 6' (300x180cm)	SP-C106PF	XX	XX

### Non Extendable Curtain Full Height :


Non - extendable curtains are supplied with eyelets on sides to tie to the frame with nylon ties.

Sizes	Curtain Only	Frame Only	Frame & Curtain
Full Length	Pkng: 10 pcs/box	Pkng: 1pc/box	Pkng: 1 set/box
4' x 6' (120x180cm)	SP-C46PNF	SP-F46	SP-FC46PNF
6' x 6' (180x180cm)	SP-C66PNF	SP-F66	SP-FC66PNF
8' x 6' (240x180cm)	SP-C86PNF	SP-F86	SP-FC86PNF
10' x 6' (300x180cm)	SP-C106PNF	XX	XX

## Accessories available

<b>SP-NT8</b> 8" Nylon Tie 	<b>SP-RING 2</b> Curtain Ring-2 
<b>SP-RING-V</b> Curtain Ring-V 	<b>WLC-25T</b> 2.5" Castor with Bolt 
<b>SP-WCFC22</b> Frame Connector 	


Frame Connector (SP-WCFC22) is used to connect two welding curtain frames to make a long welding curtain wall.



# SAFETYARC Modular Welding Curtains Assembly Instructions


## Assembly Instructions

1. 1st assemble the frame like the one shown on right, by following steps 1, 2 & 3 shown below.
2. Each joint has matching number stickers on the male and female ends.
3. Line up the matching numbers, and push in male-female ends to lock.  
For example: Line up male #1 with female #1 and lock pipes together.
4. After step 3, put Castors (if applicable). Castors are optional.



### Pre-Assembled Leg


Identify the legs below in the box.



### STEP 1


#### Assemble bottom horizontal section

Join matching numbers as shown below:





### STEP 2

#### Assemble vertical section



### STEP 3

#### Assemble top horizontal section



- If curtain has been purchased with the frame, then attach curtain to metal frame using nylon ties or metal rings.

*Your welding curtain frame is now ready to use!*